

Ver 2 LaGard Swingbolt and S & G Z02 & Z03

MAG557315

This template is designed with drill points for the Version 2 LaGard swingbolt locks.

The labels (printed letters on template) are defined as follows:

S1 - Solenoid for left hand mounted lock - Z02 Solenoid

S2 - Solenoid for right hand mounted lock

To use this template, you must know the handing of the lock, right or left hand. Once this has been determined, you will mount the template to the door. In place of the two screws that hold the entry pad onto the door, use the two 8-32 screws supplied.

To orientate the template on the door, you would mount the bolt side toward the same direction as the lock bolt. With the template in place you are now ready to drill.

To mount the Bullet II Base to the template, choose the proper drill point and attach the Bullet II Base to the template using the 8-32 screws supplied.

To open the lock drill in the location needed .

Step one, drill into the lock case so the solenoid plunger is visible.

Step two, take a wire, or ice pick and push the solenoid plunger back, and retract the lock bolt by turning the safe handle.

NOTE: This template is set-up to drill down the spindle hole.

