S&G, ILCO and LaGard Template

MAG557302

This template was designed with drill points for the following locks:

- a) Sargent and Greenleaf 6600, 6700, 8400 and 8500 series
- b) Ilco 67 series
- c) LaGard 3330
- d) Precision Products Inc P-67

The labels on the templates are as follows:

- F Center for the fence
- B Borescope hole next to the fence
- L Center for the lever screw
- R1 S&G, ILCO and PPI general relock position
- R2 La Gard 3330 relock

The template is illustrated with the drill points positioned for a right hand mounted lock. Depending on the lock mounting in the safe, the template can be rotated and mounted for any lock handing.

To mount the template, remove the dial and dial ring from the safe. Use the provided 8-32 screws to secure the template to the safe, orienting the template in the proper handing position. To mount the **Bullet II** base to the template, choose the proper drill point and attach the **Bullet II** base to the template using the 8-32 screws.



